

CATALOGUE

REVISION

1.0

FOREIGN OBJECT RETRIEVAL TOOLS & GUIDE TUBES

Item No.: DXX-80-000240 Document No.: KA004_1-0 FOREIGN OBJECT & DEBRIS RETRIEVAL TOOLS • GUIDE TUBES • ACCESSORY























ACCESS & IDENTIFICATION

GEOMETRY DEFINITION

2

TOOL CHOICE


For certain applications, a simple retrieval magnets in combination with fiber push poles might lead to a fast and easy retrieval job.

However, more frequent foreign object search and retrieval requires the use of additional endoscopic cameras to locate and identify the foreign object first. The only possible access to the location could require sophisticated guiding of cameras and tools.

Object shape and material characteristics demand specific perhaps even motorized retrieval tools.

Being knowledgeable on tools options, having equipment ready and at hands is the key of a good FOSAR prevention plan.















SEARCH & LOCATE

INVIZ® guide tubes

IDENTIFY & SECURE

INVIZ® inspection equipment

RETRIEVE

INVIZ® retrieval tools

This catalogue offers a broad range of field proven solutions for your FOSAR prevention strategy. The tool range proposed evolved over the years as result of our own and customers experiences in many successful foreign object search and retrieval scenarios.

Find basic tools, well filled and ready to go emergency retrieval tools kits, and sophisticated guiding and retrieval solutions. Many tools merge and combine seamless with each other. Our videoscopes and video endoscopes catalogue provides perfect inspection equipment fitting the range of guide tubes and retrieval tools for the search part of the FOSAR tasks.

And in case the offered equipment won't fit your specific situation, find inspirations with some interesting specials and feel free to contact us for a solution with your needs.











+49 7432 98375-0

Call us with your specific requirements.

INFO@VIZAAR.COM

Write us your detailed application description.

FIND YOUR LOCAL DEALER

Find your official sales & service distributor online.



Remote inspection & supporting tools solutions

| | RETRIEVAL TOOLS | 06 |
|-----|---------------------------------------|----|
| 1.1 | INVIZ® Retrieval Tools kits | 08 |
| 1.2 | Motorized retrieval tool INVIZ® GR 8 | 14 |
| 1.3 | Motorized retrieval tool INVIZ® GR 16 | 15 |
| 1.4 | Non-motorized retrieval tools | 16 |
| 1.5 | Retrieval pliers | 17 |
| 1.6 | Accessory | 19 |

| 2 | GUIDE TUBES | 23 |
|-----|------------------------------|----|
| 2.1 | Non-articulating guide tubes | 25 |
| 2.2 | Articulating guide tubes | 26 |

| 3 | SPECIAL RETRIEVAL TOOLS | 27 |
|-----|--|----|
| 3.1 | Articulating guide tube INVIZ® GR 22 with integrated camera and LED illumination | 29 |
| 3.2 | Retrieval snares with emergency release mechanism | 29 |
| 3.3 | Articulating guide tube INVIZ® GR 6 with gas nozzle | 29 |
| 3.4 | Pneumatic articulating guide tube system INVIZ® GR 10 | 30 |
| 3.5 | Articulating guide tube INVIZ® GR 25 with 12 mm working channel | 30 |
| 3.6 | INVIZ® DE 2.4 with retrieval hook | 30 |

© Copyright viZaar AG. Illustrations may differ from the original. Subject to technical modifications and errors. All rights reserved. All specifications are subject to change without notice due to technical progress.









Good FME (Foreign Material Exclusion) programs minimize FOD (Foreign Object Debris). But problems still occur and often at the worst moment. FOD can be almost anything, from a lost fastener to a dropped mobile phone. When FOD shows up results can be destructive, dangerous and massively expensive. The selected tool kits are the result of long experience and practical use. The tools are practically packed in one tailor made carrying case. Typical standard tools and practical consuming materials are included. Besides good materials debris prevention, a well filled retrieval tool kit being ready at side is the best strategy and preparation to counter the unexpected.



1.1 INVIZ® Retrieval tools kits



| INVIZ® | Retrieval | tools | kit |
|--------|-----------|-------|-----|
| | PRO | | |

Including:

- Motorized retrieval tool INVIZ® GR 8
- Motorized retrieval tool INVIZ® GR 16
- Stainless steel wire snare
- Retrieval magnets
- Hook tool
- Adjustable elbow
- LED flash light
- Tool set
- Accessory set
- Glass fiber push pole set
- Operating instructions

| INVIZ® GR 8 | INVIZ® GR 16 | NON-MOTORIZED RETRIEVAL TOOLS | ACCESSORY SET | PUSH POLE SET | SYSTEM KIT |
|------------------|--------------|-------------------------------|---------------|---------------|---------------|
| ✓ 10 m | ~ | ~ | ~ | ~ | BMX-50-000231 |
| ✓ 15 m | ~ | • | ~ | ~ | BMX-50-000345 |

The PRO version is the most complete retrieval tools kit you will find, tailored in one mobile hand case. It is the professional's choice. In addition to a full set of standard equipment, it contains two different sized electrical driven retrieval tools with four different grabber options.

| 0 | Motorized retrieval tool INVIZ® GR 8 Motorized and waterproof 8 mm retrieval tool with 10 m / 15 m working length. | VXX-70-000104 VXX-70-000105 |
|--|--|--------------------------------|
| • } | Interchangeable T-Rex mouth for INVIZ® GR 8 8 mm T-Rex mouth, including spare grub screws and Allen key (FXX-70-000112). | BMX-50-000334 |
| | Interchangeable Dolphin mouth for INVIZ® GR 8 Dolphin mouth, including spare grub screws and Allen key (FXX-70-000112). | BMX-50-000335 |
| | Remote control INVIZ® GR 8 Remote control for the retrieval tool INVIZ® GR 8. | BMX-50-000256 |
| Charles, | Battery 1x powerful spare battery Ultralite Lithium HI Energy 9-V Block | EXX-91-000106 |
| MOTORIZED RET | RIEVAL TOOL INVIZ® GR 16 | |
| The same of the sa | Motorized retrieval tool INVIZ® GR 16 Motorized and waterproof 16 mm retrieval tool. | BEM-30-000165 |
| | Remote control INVIZ® GR 16 Remote control for the retrieval tool INVIZ® GR 16. | BMX-50-000249 |
| | Cable for remote control INVIZ® GR 16 15 m cable for remote control retrieval tool INVIZ® GR 16. | BEX-20-000113 |
| Commission of the Commission o | Battery 2x powerful spare battery Ultralite Lithium HI Energy 9-V Block | EXX-91-000106 |

| STAINLESS STEEL | BMX-50-000115 | | |
|-----------------|---------------|-------------------------------|--|
| 6 | Diameter | 2.5 mm | |
| | Length | 15 m | |
| | Construction | Multi wire snare construction | |
| | Mounting | 10 mm push pole adapter | |
| | Function | Offering big size loops | |

Other configurations, spare parts and accessories are available in further chapters.





Fork & Tine tools for motorized retrieval pliers INVIZ $^{\odot}$ GR 16. Including Allen key (FXX-70-000112).



1.1 INVIZ® Retrieval tools kits

Including

| RETRIEVAL HOOK | RETRIEVAL HOOK BMX-50-000117 | | | | | |
|-----------------------------------|------------------------------|--|--------------------------|--|--|--|
| \sim | Function | Reinforced, sharp hook | | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| | - | | | | | |
| RETRIEVAL MAGNET, SMALL BMX-50-00 | | | | | | |
| KETKIEVAL MAGIN | Dimensions | Ø 16 x 40 mm | BMX-50-000113 | | | |
| | | | | | | |
| | Mounting Function | 10 mm push pole adapter | | | | |
| | Function | Small size magnet for limited space applications. | | | | |
| RETRIEVAL MAGN | IET, MEDIUM | | BMX-50-000112 | | | |
| | Dimensions | Ø 20 x 40 mm | | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| | Function | Medium size magnet a compromise space and magneti | c strength. | | | |
| RETRIEVAL MAGN | IET. LARGE | | BMX-50-000114 | | | |
| | Dimensions | Ø 24 x 45 mm | | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| | Function | Strong magnet for bigger items and larger amount meta | al chip collection. | | | |
| ADJUSTABLE ELBO | 014 | | BMX-50-000106 | | | |
| ADJUSTABLE ELBO | | 00 += 000 | BIVIX-50-000 106 | | | |
| | Angle | 0° to 90° | | | | |
| 9 | Mounting | 10 mm push pole adapter | | | | |
| | Function | Better tool positioning for retrieval snares, magnets, hooks or ret | 1eval tool INVIZ® GR 16. | | | |
| SHORT ROD PIEC | E 10 CM / 4" | | FXX-71-000124 | | | |
| | Function | Optimized for operation with adjustable elbow (BMX-50 | -000106) | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| GLASS FIBER PUS | H POLE SET | | BMX-50-000292 | | | |
| | 3x Glass fiber pu | sh pole "soft", each 1,5 meter length | FXX-71-000100 | | | |
| | | and extend by the tool free 10 mm interconnector. | 1700 71 000100 | | | |
| | 3v Glass fiber nu | sh pole "medium", each 1,5 meter length | FXX-71-000101 | | | |
| | FXX-71-000101 | | | | | |
| | 2v Class files | nh nala "atiff" anah 4 F matau langth | E0/21 000/5 | | | |
| | | sh pole "stiff", each 1,5 meter length and extend by the tool free 10 mm interconnector. | FXX-71-000102 | | | |
| | | | | | | |
| SOFT BAG FOR GL | ASS FIBER PUSH P | OLES | FXX-82-000108 | | | |
| | | | | | | |



This soft bag stores up to 15 of your connectable glass fiber push poles. Made from robust easy to clean materials, it will be simple to transport and store your full length push rod system.



This robust case is home for retrieval tools and accessories. Light-weight, compact and splash water proof HPX® high performance transport case for INVIZ® retrieval tools. Product tailored interior for perfect protection during transport and storage. \\



Screw driver set, wire cutter, LED power flash lamp, scissors; cutter and all other usefull tools to fit and refill the Retrieval tool case.

9



Duct tape, cable binder and all those useful consumables all ready packed into the practical tailored plastic containers to refill the retrieval tool box.

+49 7432 98375-0

1.1 INVIZ® Retrieval tools kits



INVIZ® Retrieval tools kit **STANDARD**

Including:

- Motorized retrieval tool INVIZ® GR 8
- Stainless steel wire snare
- Retrieval magnets
- Hook tool
- Adjustable elbow
- LED flash light
- Tool set
- Accessory set
- Glass fiber push pole set
- Operating instructions

| INVIZ® GR 8 | INVIZ® GR 16 | NON-MOTORIZED RETRIEVAL TOOLS | ACCESSORY SET | PUSH POLE SET | SYSTEM KIT |
|-------------|--------------|-------------------------------|---------------|---------------|---------------|
| ✓ | - | ✓ | ~ | ~ | BMX-50-000268 |
| 10 m | | | | | |

The STANDARD version retrieval tools kit offers a very complete set of mechanical foreign object retrieval equipment packed together with the world's smallest electrical driven retrieval tool system INVIZ® GR 8. Two field interchangeable grabbers expand the scope of capabilities.

The recommended optional INVIZ® GR 16 fits perfectly into the same case and upgrades the set to the PRO version.

| MOTORIZED RETRIEVAL TOOL INVIZ® GR 8 | | | | | |
|--------------------------------------|---|--------------------------------|--|--|--|
| 9 | Motorized retrieval tool INVIZ® GR 8 Motorized and waterproof 8 mm retrieval tool with 10 m / 15 m working length. | VXX-70-000104 VXX-70-000105 | | | |
| | Interchangeable T-Rex mouth for INVIZ® GR 8 8 mm T-Rex mouth, including spare grub screws and Allen key (FXX-70-000112). | BMX-50-000334 | | | |
| e cur | Interchangeable Dolphin mouth for INVIZ® GR 8 Dolphin mouth, including spare grub screws and Allen key (FXX-70-000112). | BMX-50-000335 | | | |
| | Remote control INVIZ® GR 8 Remote control for the retrieval tool INVIZ® GR 8. | BMX-50-000256 | | | |
| , Charles | Battery 1x powerful spare battery Ultralite Lithium HI Energy 9-V Block | EXX-91-000106 | | | |

| STAINLESS STEEL | BMX-50-000115 | | |
|-----------------|---------------|-------------------------------|---------------|
| 6 | Diameter | 2.5 mm | |
| | Length | 15 m | |
| | Construction | Multi wire snare construction | |
| | Mounting | 10 mm push pole adapter | |
| | Function | Offering big size loops | |
| | | | |
| RETRIEVAL HOOF | | | BMX-50-000117 |
| | Function | Reinforced, sharp hook | |
| | Mounting | 10 mm push pole adapter | |
| | | | |

Other configurations, spare parts and accessories are available in further chapters.







1.1 INVIZ® Retrieval tools kits

Including

| RETRIEVAL MAGNET, SMALL BMX-50-000113 | | | | | | |
|---------------------------------------|--|--|--------------------------|--|--|--|
| | Dimensions | Ø 16 x 40 mm | | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| | Function | Small size magnet for limited space applications. | | | | |
| RETRIEVAL MAGI | BMX-50-000112 | | | | | |
| | Dimensions | Ø 20 x 40 mm | | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| | Function | Medium size magnet a compromise space and magnetic | strength. | | | |
| RETRIEVAL MAGI | NET, LARGE | | BMX-50-000114 | | | |
| | Dimensions | Ø 24 x 45 mm | | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| | Function | Strong magnet for bigger items and larger amount meta | l chip collection. | | | |
| ADJUSTABLE ELB | ow | | BMX-50-000106 | | | |
| | Angle | 0° to 90° | | | | |
| an . | Mounting | 10 mm push pole adapter | | | | |
| | Function | Better tool positioning for retrieval snares, magnets, hooks or retr | ieval tool INVIZ® GR 16. | | | |
| SHORT ROD PIEC | E 10 CM / 4" | | FXX-71-000124 | | | |
| | Function | Optimized for operation with adjustable elbow (BMX-50- | 000106) | | | |
| | Mounting | 10 mm push pole adapter | | | | |
| GLASS FIBER PUS | SH POLE SET | | BMX-50-000292 | | | |
| | FXX-71-000100 | | | | | |
| | 3x Glass fiber push pole "medium", each 1,5 meter length Simply to connect and extend by the tool free 10 mm interconnector. | | | | | |
| | 3x Glass fiber pu | FXX-71-000102 | | | | |

SOFT BAG FOR GLASS FIBER PUSH POLES

FXX-82-000108



This soft bag stores up to 15 of your connectable glass fiber push poles. Made from robust easy to clean materials, it will be simple to transport and store your full length push rod system.

Simply to connect and extend by the tool free 10 mm interconnector.

TRANSPORT CASE

BMX-50-000230



This robust case is home for retrieval tools and accessories. Light-weight, compact and splash water proof HPX® high performance transport case for INVIZ® retrieval tools. Product tailored interior for perfect protection during transport and storage.

STANDARD TOOLS SE

BSX-90-000101



Screw driver set, wire cutter, LED power flash lamp, scissors; cutter and all other usefull tools to fit and refill the Retrieval tool case.

RETRIEVAL TOOL CONSUMABLES

11

BSX-90-00010



 $\label{thm:consumables} Duct tape, cable binder and all those useful consumables all ready packed into the practical tailored plastic containers to refill the retrieval tool box.$



1.1 INVIZ® Retrieval tools kits



INVIZ® Retrieval tools kit **START**

Including:

- Stainless steel wire snare
- Retrieval magnets
- Hook tool
- Adjustable elbow
- LED flash light
- Tool set
- Accessory set
- Glass fiber push pole set
- Operating instructions

| INVIZ® GR 8 | INVIZ® GR 16 | NON-MOTORIZED RETRIEVAL TOOLS | ACCESSORY SET | PUSH POLE SET | SYSTEM KIT |
|-------------|--------------|-------------------------------|---------------|---------------|---------------|
| - | - | ✓ | ~ | ~ | BMX-50-000269 |

The START retrieval tools kit offers the complete range of basic mechanical retrieval tools fitting seamless onto the extendable push rod poles. Practical accessories and hand tools support you and ensure that you are prepared and ready to go when the emergency pops up.

The recommended optional electrical retrieval tools INVIZ® GR 8 and INVIZ® GR 16 fit perfectly into the tailormade case and upgrade the system to the PRO version.

| STAINLESS STEEL | WIRE SNARE | | BMX-50-000115 |
|-----------------|--------------|--|----------------|
| 6 | Diameter | 2.5 mm | |
| | Length | 15 m | |
| | Construction | Multi wire snare construction | |
| | Mounting | 10 mm push pole adapter | |
| | Function | Offering big size loops | |
| | | | |
| RETRIEVAL HOOF | < | | BMX-50-000117 |
| | Function | Reinforced, sharp hook | |
| | Mounting | 10 mm push pole adapter | |
| | | | |
| | | | |
| RETRIEVAL MAGI | NET, SMALL | | BMX-50-000113 |
| | Dimensions | Ø 16 x 40 mm | |
| | Mounting | 10 mm push pole adapter | |
| | Function | Small size magnet for limited space applications. | |
| | | | |
| RETRIEVAL MAG | NET, MEDIUM | | BMX-50-000112 |
| | Dimensions | Ø 20 x 40 mm | |
| | Mounting | 10 mm push pole adapter | |
| | Function | Medium size magnet a compromise space and magnetic s | strength. |
| | | | |
| RETRIEVAL MAGI | NET, LARGE | | BMX-50-000114 |
| | Dimensions | Ø 24 x 45 mm | |
| | Mounting | 10 mm push pole adapter | |
| | Function | Strong magnet for bigger items and larger amount metal | hin collection |



1.1 INVIZ® Retrieval tools kits

Including

| ADJUSTABLE ELE | BOW | BMX-50-000106 |
|----------------|---------------|--|
| | Angle | 0° to 90° |
| and the second | Mounting | 10 mm push pole adapter |
| | Function | Better tool positioning for retrieval snares, magnets, hooks or retrieval tool INVIZ® GR 16. |
| SHORT ROD PIE | CE 10 CM / 4" | FXX-71-000124 |
| Function | | Optimized for operation with adjustable elbow (BMX-50-000106) |

10 mm push pole adapter

| GLASS FIBER PUS | BMX-50-000292 | |
|-----------------|---|---------------|
| | 3x Glass fiber push pole "soft", each 1,5 meter length Simply to connect and extend by the tool free 10 mm interconnector. | FXX-71-000100 |
| | 3x Glass fiber push pole "medium", each 1,5 meter length Simply to connect and extend by the tool free 10 mm interconnector. | FXX-71-000101 |
| | 3x Glass fiber push pole "stiff", each 1,5 meter length Simply to connect and extend by the tool free 10 mm interconnector. | FXX-71-000102 |

Mounting



This soft bag stores up to 15 of your connectable glass fiber push poles. Made from robust easy to clean materials, it will be simple to transport and store your full length push rod system.



This robust case is home for retrieval tools and accessories. Light-weight, compact and splash water proof HPX® high performance transport case for INVIZ® retrieval tools. Product tailored interior for perfect protection during transport and storage.



Screw driver set, wire cutter, LED power flash lamp, scissors; cutter and all other usefull tools to fit and refill the Retrieval tool case.



Duct tape, cable binder and all those useful consumables all ready packed into the practical tailored plastic containers to refill the retrieval tool box.



1.2 Motorized retrieval tool INVIZ® GR 8



| OUTER Ø | LENGTH | ITEM NO. |
|---------|--------|---------------|
| 8.4 mm | 10 m | VXX-70-000104 |
| 8.4 mm | 15 m | VXX-70-000105 |
| 8.4 mm | 20 m | VXX-70-000106 |
| 8.4 mm | 30 m | VXX-70-000107 |

Transport case (BMX-50-000230), T-Rex mouth grabber (BMX-50-000334) and Dolphin mouth grabber (BMX-50-000335) must be ordered seperately.

The INVIZ® GR 8 is included in the INVIZ® Retrieval tools kits PRO and STANDARD.

Motorized retrieval tool INVIZ® GR 8

Including:

- 2 m umbilical cable
- Remote control
- Lithium high power battery
- Storage box
- Operating instructions

The INVIZ® GR 8 is a motorized gripper, fixed and powered through a flexible and robust glass fiber push rod. It is designed to retrieve smaller and medium size items. Depending on the need, object shape and position, the jaw can be swapped from a 5 mm mouse tooth gripper to a 8 mm T-Rex mouth gripper. Operated by remote control, the retrieval tool is battery powered. Avoid cable clutter with the smart storage push rod system with integrated power supply cords. It's push rod is stored in a practical box and provided in one working length, thus very useful in narrow surroundings. The INVIZ® GR 8 will perfectly fit into the retrieval tool case.

Recommended accessory

- Transport case
- T-Rex mouth grabber
- Dolphin mouth grabber

| TRANSPORT CASE | BMX-50-000230 |
|----------------|---------------|
| | |



This robust case is home for retrieval tools and accessories. Light-weight, compact and splash water proof HPX® high performance transport case for INVIZ® retrieval tools. Product tailored interior for perfect protection during transport and storage.

| INTERCHANGEABLE T-REX MOUTH GRABBER FOR INVIZ® GR 8 BMX-50-0003 | | | MX-50-000334 |
|---|-----------------------|---|--------------|
| | Outer Ø (jaws closed) | 8.4 mm | |
| | Distal head length | 108 mm | |
| Jaw range 70° Space required to open jaws to | | 70° Space required to open jaws to maximum 16.8 | 3 mm |
| Max. grab size 12.5 mm | | 12.5 mm | |

| INTERCHANGEABLE DOLPHIN MOUTH GRABBER FOR INVIZ® GR 8 | | GRABBER FOR INVIZ® GR 8 BMX-50-000335 |
|---|-----------------------|--|
| | Outer Ø (jaws closed) | 8.4 mm |
| - Con - Con- | Distal head length | 125 mm |
| | Jaw range | 70° Space required to open jaws to maximum 32 mm |
| | Max. grab size | 28 mm |

| | Outer Ø | 22.0 mm |
|----------------|--------------------|--|
| ARTICULATING G | UIDE TUBE, 3 M | HVT-90-000148 |
| | | |
| | Max. grab size | 28 mm |
| | Jaw range | 70° Space required to open jaws to maximum 32 mm |
| | Distal head length | 125 mm |

| ARTICULATING GUIDE TUBE, 3 M | | HVT-90-000148 | |
|------------------------------|--------------|---------------|--|
| | Outer Ø | 22.0 mm | |
| | Length | 3 m | |
| | Articulation | 4 x 110° | |
| | Inner Ø | 9.0 mm | |

| ARTICULATING GUIDE TUBE, 5 M | | HVT-90-000149 | |
|---|--------------|---------------|--|
| Outer Ø 22.0 mm Length 5 m Articulation 4 x 110° Inner Ø 9.0 mm | 22.0 mm | | |
| | 5 m | | |
| | Articulation | 4 x 110° | |
| | Inner Ø | 9.0 mm | |
| | | | |

Optional useful accessory

Articulating guide tubes

1.3 Motorized retrieval tool INVIZ® GR 16



| OUTER Ø | CABLE LENGTH* | ITEM NO. |
|---------|---------------|---------------|
| 16 mm | 15 m | BEM-30-000219 |

* Custom lengths available up to 30 m. Transport case (BMX-50-000230) must be ordered separately. The INVIZ® GR 16 is included in the INVIZ® Retrieval tools kit PRO.

Motorized retrieval tool INVIZ® GR 16

Including:

- 15 m umbilical cable
- Remote control
- Battery
- Storage box
- Operating instructions

The INVIZ® GR 16 is the workhorse of motorized retrieval tools. Medium size and larger objects are secure gripped and retrieved. Grabs are field interchangeable between an alligator style and a three finger grabber. The alligator mouth including four adjustable front fangs securing additional grip on the object. The viZaar® push rod quick connection system integrates seamlessly with the INVIZ® GR 16 to assist accurate positioning. The flexible push rods used in this system are available in a selection of different lengths and three grades of stiffness. Made of robust stainless steel, the INVIZ® GR 16 is robust, watertight and mobile, powered by two lithium ion batteries.

Recommended accessory

- Transport case
- Three finger jaws



This robust case is home for retrieval tools and accessories. Light-weight, compact and splash water proof HPX® high performance transport case for INVIZ® retrieval tools. Product tailored interior for perfect protection during transport and storage.

| INTERCHANGEA | INTERCHANGEABLE THREE FINGER JAWS FOR INVIZ® GR 16 | | |
|--------------|--|---|---|
| | Outer Ø (jaws closed) | 16 mm | |
| | Length | 49 mm | |
| | Distal head length | 219 mm | |
| | Jaw range | 160° Space required to open jaws to maximum 84 mr | m |
| | Max. grab size | 77 mm | |

1.4 Non-motorized retrieval tools



| STAINLESS STEEL WIR | STAINLESS STEEL WIRE SNARE | | |
|---------------------|---|--|--|
| Diameter | 2.5 mm | | |
| Length | 15 m | | |
| Construction | Multi wire snare construction | | |
| Mounting | 10 mm push pole adapter | | |
| Function | Offering big size loops | | |
| Recommended | Glass fiber push pole soft / medium / stiff | | |

Stainless steel wire snare



| RETRIEVAL HOOK | | BMX-50-000117 |
|----------------|---|---------------|
| Function | Reinforced, sharp hook | |
| Mounting | 10 mm push pole adapter | |
| Recommended | Glass fiber push pole soft / medium / stiff | |

Retrieval hook



| RETRIEVAL MAGNET, | SMALL | BMX-50-000113 |
|-------------------|--|---------------|
| Dimensions | Ø 16 x 40 mm | |
| Mounting | 10 mm push pole adapter | |
| Function | Small size magnet for limited space applications. | |
| Recommended | Flex rod 15 cm / 6" (FXX-71-000105) and glass fiber push pole soft / med | dium / stiff. |

Retrieval magnet, small



| RETRIEVAL MAGNET, | MEDIUM | BMX-50-000112 |
|-------------------|--|-----------------|
| Dimensions | Ø 20 x 40 mm | |
| Mounting | 10 mm push pole adapter | |
| Function | Medium size magnet a compromise space and magnetic strength. | |
| Recommended | Flex rod 15 cm / 6" (FXX-71-000105) and glass fiber push pole soft / m | nedium / stiff. |

Retrieval magnet, medium



| RETRIEVAL MAGNET, LARGE | | BMX-50-000114 |
|-------------------------|--|----------------|
| Dimensions | Ø 24 x 45 mm | |
| Mounting | 10 mm push pole adapter | |
| Function | Strong magnet for bigger items and larger amount metal chip collection | on. |
| Recommended | Flex rod 15 cm / 6" (FXX-71-000105) and glass fiber push pole soft / m | edium / stiff. |


Retrieval magnet, large

16

1.5 Retrieval pliers




| OUTER Ø | LENGTH | PLIERS | JAW RANGE | PLIER LENGTH | FITTING TO | ITEM NO. |
|---------|--------|-------------------|-----------|--------------|--|---------------|
| 1.65 mm | 3.3 m | Alligator forceps | 100° | 10.2 mm | VUCAM® XO (3.3 m) | HSO-50-000100 |
| 1.65 mm | 7.0 m | Alligator forceps | 100° | 10.2 mm | INVIZ® DE 2.4 / 4.0 VUCAM® XO (6.6 m) | HSO-50-000101 |
| 3.0 mm | 2.2 m | Alligator forceps | 90° | 16.7 mm | VUCAM® XO (2.2 m) VISIO probes | HSO-50-000102 |
| 3.0 mm | 3.3 m | Alligator forceps | 90° | 16.7 mm | VUCAM® XO (3.3 m) VISIO probes | HSO-50-000103 |
| 3.0 mm | 6.6 m | Alligator forceps | 90° | 16.7 mm | VUCAM® XO (6.6 m) INVIZ® VUMAN® (5 m) | HSO-50-000104 |
| 3.0 mm | 9.0 m | Alligator forceps | 90° | 16.7 mm | INVIZ® VUMAN® (8 m) | HSO-50-000105 |




| OUTER Ø | LENGTH | PLIERS | JAW RANGE | PLIER LENGTH | FITTING TO | ITEM NO. |
|---------|--------|-----------------|-----------|--------------|---|---------------|
| 1.65 mm | 3.3 m | Three pongs jaw | > 15 mm | 36 mm | VUCAM® XO (3.3 m) INVIZ® GR 17 (3 m) INVIZ® GR 22 (3 m) | HSO-50-000106 |
| 1.65 mm | 7.0 m | Three pongs jaw | > 15 mm | 36 mm | INVIZ® DE 2.4 / 4.0 VUCAM® XO (6.6 m) | HSO-50-000107 |



| OUTER Ø | LENGTH | PLIERS | JAW RANGE | PLIER LENGTH | FITTING TO | ITEM NO. |
|---------|--------|---------------------------|-----------|--------------|---|---------------|
| 6.0 mm | 3.3 m | Foreign body retriever | > 30 mm | 97.7 mm | VUCAM® XO (3.3 m) INVIZ® GR 17 (3 m) INVIZ® GR 22 (3 m) | HSO-50-000108 |
| 6.0 mm | 7.0 m | Foreign body retriever | > 30 mm | 97.7 mm | VUCAM® XO (6.6 m) VISIO probes INVIZ® GR 17 INVIZ® GR 22 | HSO-50-000109 |



| OUTER Ø | LENGTH | PLIERS | JAW RANGE | PLIER LENGTH | FITTING TO | ITEM NO. |
|---------|--------|--------------------------------------|-----------|--------------|---|---------------|
| 6.0 mm | 3.3 m | Alligator forceps, cross serrated | Min. 85° | 37.0 mm | VUCAM® XO (3.3 m) INVIZ® GR 17 (3 m) INVIZ® GR 22 (3 m) | HSO-50-000110 |
| 6.0 mm | 7.0 m | Alligator forceps, cross serrated | Min. 85° | 37.0 mm | VUCAM® XO (6.6 m) VISIO probes INVIZ® GR 17 INVIZ® GR 22 | HSO-50-000111 |



| οι | JTER Ø | LENGTH | PLIERS | JAW RANGE | PLIER LENGTH | FITTING TO | ITEM NO. |
|----|--------|--------|-----------|-----------|--------------|---|---------------|
| 6. | .0 mm | 3.3 m | Rat tooth | Min. 85° | 36.9 mm | | HSO-50-000112 |
| 6. | .0 mm | 7.0 m | Rat tooth | Min. 85° | 37.0 mm | VUCAM® XO (6.6 m) VISIO probes INVIZ® GR 17 INVIZ® GR 22 | HSO-50-000113 |

Retrieval pliers

In the medical world, tools like this are frequently used for keyhole operations and foreign object retrieval inside the human body. The following retrieval tools utilize the known advantages and have been adapted and improved for industrial applications.

Small alligator forceps with spring mechanism, snares and three prong retriever offer good grip and high flexibility in industrial applications. The working length is adapted to typical industrial working lengths of industrial videoscopes like the VUCAM® XO.

1.5 Retrieval pliers



| OUTER Ø | LENGTH | ARTICULATION | PLIERS | CONSTRUCTION | ITEM-NO. |
|---------|--------|--------------|----------------------|--------------|---------------|
| 19.0 mm | 3.3 m | 4 x 110° | Alligator | Plastic | HSO-50-000114 |
| 19.0 mm | 3.3 m | 4 x 110° | Three finger grabber | Plastic | HSO-50-000115 |
| 19.0 mm | 5.3 m | 4 x 90° | Alligator | Plastic | HSO-50-000116 |
| 19.0 mm | 5.3 m | 4 x 90° | Three finger grabber | Plastic | HSO-50-000117 |

GR 19



| OUTER Ø | LENGTH | ARTICULATION | PLIERS | CONSTRUCTION | ITEM-NO. |
|---------|--------|--------------|----------------------|-----------------|---------------|
| 22.0 mm | 3.3 m | 4 x 110° | Alligator | Stainless steel | HSO-50-000118 |
| 22.0 mm | 3.3 m | 4 x 110° | Three finger grabber | Stainless steel | HSO-50-000119 |
| 22.0 mm | 5.3 m | 4 x 90° | Alligator | Stainless steel | HSO-50-000120 |
| 22.0 mm | 5.3 m | 4 x 90° | Three finger grabber | Stainless steel | HSO-50-000121 |

GR 22

1.6 Accessory



Alligator jaws INVIZ® GR 16





Three finger jaws INVIZ® GR 16

| INTERCHANGEABLE THREE FINGER JAWS FOR INVIZ® GR 16 BMX-50-000293 | | |
|--|---|--|
| Diameter (jaws closed) | 16 mm | |
| Length | 49 mm | |
| Distal head length | 219 mm | |
| Jaw range | 160° Space required to open jaws to maximum 84 mm | |
| Max. grab size | 77 mm | |
| Function | Incl. Allen key | |



T-Rex grabber INVIZ® GR 8

| INTERCHANGEABLE T | INTERCHANGEABLE T-REX MOUTH GRABBER FOR INVIZ® GR 8 BMX-50-000334 | | |
|------------------------|---|--|--|
| Diameter (jaws closed) | 8.4 mm | | |
| Distal head length | 108 mm | | |
| Jaw range | 70° Space required to open jaws to maximum 16.8 mm | | |
| Max. grab size | 12.5 mm | | |
| Function | Incl. Allen key and spare grub screws | | |



Dolphin grabber INVIZ® GR 8

| INTERCHANGEABLE DOLPHIN MOUTH GRABBER FOR INVIZ® GR 8 BMX-50-000335 | | |
|---|--|--|
| Diameter (jaws closed) | 8.4 mm | |
| Distal head length | 125 mm | |
| Jaw range | 70° Space required to open jaws to maximum 32 mm | |
| Max. grab size | 28 mm | |
| Function | Incl. Allen key and spare grub screws | |



Transport case

TRANSPORT CASE BMX-50-000230

This robust case is home for retrieval tools and accessories. Light-weight, compact and splash water proof $HPX^{\$} \ high \ performance \ transport \ case \ for \ INVIZ^{\$} \ retrieval \ tools. \ Product \ tailored \ interior \ for \ perfect \ protection$ during transport and storage.



1.6 Accessory



| Glass fiber push pole |
|-----------------------|
|-----------------------|

| GLASS FIBER PUSH POLE, SOFT | | FXX-71-000100 |
|-----------------------------|--------------------------------------|---------------|
| Diameter | 6.0 mm | |
| Construction | PE coated glass fiber push pole | |
| Length | 1.5 m | |
| Mounting | 10 mm stainless steel quick coupling | |



| CI | 200 | file | 0 10 | 0110 | h | 00 | |
|-----|-----|------|------|------|----|---------------|----|
| G I | d55 | HU | 91 | pus | 11 | $\rho \sigma$ | IE |

| GLASS FIBER PUSH POLE, MEDIUM | | FXX-71-000101 |
|-------------------------------|--------------------------------------|---------------|
| Diameter | 7.5 mm | |
| Construction | PE coated glass fiber push pole | |
| Length | 1.5 m | |
| Mounting | 10 mm stainless steel quick coupling | |



Glass fiber push pole

| GLASS FIBER PUSH POLE, STIFF | | FXX-71-000102 |
|------------------------------|--------------------------------------|---------------|
| Diameter | 9.0 mm | |
| Construction | PE coated glass fiber push pole | |
| Length | 1.5 m | |
| Mounting | 10 mm stainless steel quick coupling | |



Soft bag

SOFT BAG FOR GLASS FIBER PUSH POLES

FXX-82-000108

This soft bag stores up to 15 of your connectable glass fiber push poles. Made from robust easy to clean materials, it will be simple to transport and store your full length push rod system.



Adjustable elbow

| ADJUSTABLE ELBOW | | BMX-50-000106 |
|------------------|---|-----------------------|
| Angle | 0° to 90° | |
| Mounting | 10 mm push pole adapter | |
| Function | Better tool positioning for retrieval snares, magnets, hooks or retrieval | al tool INVIZ® GR 16. |



Short rod piece

| LENGTH | FUNCTION | MOUNTING | ITEM NO. |
|--------|---|-------------------------|---------------|
| 100 mm | Optimized for operation with adjustable elbow (BMX-50-000106) | 10 mm push pole adapter | FXX-71-000124 |
| 250 mm | Optimized for operation with adjustable elbow (BMX-50-000106) | 10 mm push pole adapter | FXX-71-000125 |

1.6 Accessory



Flex rod

| FLEX ROD 15 CM | / 6" FXX-71-000105 |
|----------------|--|
| Length | 7.0 mm |
| Mounting | 10 mm push pole adapter |
| Function | Flexible rubber push pole adapter. Recommended for operation of magnets in steel piping. |

| FXX-71-000123 |
|---------------|
| |
| |
| |

T-bar handle



| LENGTH | ITEM NO. |
|--------|---------------|
| 15 m | BEX-20-000113 |
| 20 m | BEX-20-000114 |
| 30 m | BEX-20-000115 |

Umbilical cable INVIZ® GR 16



Remote control INVIZ® GR 8

| REMOTE CONTROL INVIZ® GR 8 | BMX-50-000256 |
|--|---------------|
| Remote control for the retrieval tool INVIZ® GR 8. | |
| | |
| | |
| | |
| | |



Remote control INVIZ® GR 16



Spare battery

| REMOTE CONTROL INVIZ® GR 16 | BMX-50-000249 |
|---|---------------|
| Remote control for the retrieval tool INVIZ® GR 16. | |
| | |
| | |
| | |
| | |

SPARE BATTERY EXX-91-000106 $Powerful \ spare \ battery \ Ultralite \ Lithium \ HI \ Energy \ 9-V \ Block. \ Two \ batteries \ required for \ INVIZ \^{\tiny 9} \ GR \ 16, one \ battery$ required for INVIZ® GR 8.

1.6 Accessory



Tool set

STANDARD TOOLS SET

BSX-90-000101

Screw driver set, wire cutter, LED power flash lamp, scissors; cutter and all other usefull tools to fit and refill the retrieval tool case.



Consumables

RETRIEVAL TOOL CONSUMABLES

BSX-90-000100

Duct tape, cable binder and all those useful consumables all ready packed into the practical tailored plastic containers to refill the retrieval tool box.



Non-articulating and articulating guide tubes






Guide tubes are essential help to introduce, orientate and position inspection equipment and retrieval tools. The offered range includes simple rigid-, semi-flexible- or flexible guide tubes with working channel and remote articulation mechanism.

These multi-functional tools assist the video probe and retrieval tools during foreign objects search and retrieval operations. They too are used to clean debris or shaving. Guide tubes are utilized to suck in or blow out. In some cases they deliver and position flexible shaft drives allowing remote grinding, cutting or torque tool operation.









Non-articulating guide tubes

| OUTER Ø | FOR PROBES WITH Ø | LENGTH | CONSTRUCTION | FOR PRODUCTS | ITEM-NO. |
|---------|-------------------|--------|--------------|---|---------------|
| 5.5 mm | 3.7 mm 4.0 mm | 300 mm | Rigid | VISIO probes Fiberscopes | HVT-90-000135 |
| 6.0 mm | 4.5 mm 5.0 mm | 300 mm | Rigid | VISIO probes Fiberscopes | HVT-90-000136 |
| 8.0 mm | 6.0 mm | 500 mm | Rigid | VUCAM® VUMAN® VISIO probes Fiberscopes | HVT-90-000137 |
| 10.0 mm | 8.0 mm 8.4 mm | 500 mm | Rigid | VUMAN® VISIO probes Fiberscopes | HVT-90-000138 |
| 8.0 mm | 3.7 mm 4.0 mm | 500 mm | Semi-rigid | VISIO probes Fiberscopes | HVT-90-000139 |
| 10.0 mm | 4.5 mm 5.0 mm | 500 mm | Semi-rigid | VISIO probes Fiberscopes | HVT-90-000140 |
| 12.0 mm | 6.0 mm | 500 mm | Semi-rigid | VUCAM® VUMAN® VISIO probes Fiberscopes | HVT-90-000141 |
| 14.0 mm | 8.0 mm 8.4 mm | 500 mm | Semi-rigid | VUMAN [®] VISIO probes Fiberscopes | HVT-90-000142 |

Rigid and semi-flexible guide tubes are often used as stiffener to guide flexible probes, bridge gaps or quickly reach pre-defined positions. Guide tubes protect the equipment from sharp cutting edges and reduce wear & tear.



GUIDE TUBES

2.2 Articulating guide tubes



| OUTER Ø | INNER Ø | LENGTH | ARTICULATION | FITTING PROBE Ø | MATERIAL | ITEM NO. |
|---------|---------|--------|--------------|-----------------|-----------------|---------------|
| 19.0 mm | 6.3 mm | 3 m | 4 x 110° | 6.0 mm | Plastic | HVT-90-000150 |
| 19.0 mm | 6.3 mm | 5 m | 4 x 90° | 6.0 mm | Plastic | HVT-90-000151 |
| 22.0 mm | 9.0 mm | 3 m | 4 x 110° | 9.0 mm | Stainless steel | HVT-90-000148 |
| 22.0 mm | 9.0 mm | 5 m | 4 x 90° | 9.0 mm | Stainless steel | HVT-90-000149 |

Articulating guide tubes

Including:

Transport case

This articulating guide tubes provide four way articulation. The integrated working channel passes flexible endoscopes and retrieval tools with a maximum outer diameter of 6 mm and 9.0 mm.

Available in different diameters and working lengths, the outer sheath is made of cut resistant stainless steel or an additional shrink tube. Two solid steering knobs allow the remote articulation of the distal head together with the inserted tool or camera. The user can move the tools axial inside the tube, offering an additional axis to reach out with the grabber or adding an additional lift and rotating axis to your inspection camera. Sometimes, this is the only possibility to reach the point of interest.

The articulating guide tube with 19 mm diameter supports the videoscope VUCAM® XO, video endoscope INVIZ® VUMAN® and VISIO probes up to 6 mm diameter for search applications.

The articulating guide tube with 22 mm diameter fits the field installable, motorized retrieval tool INVIZ® GR 8 and also supports the videoscope VUCAM® XO, video endoscope INVIZ® VUMAN® and VISIO probes up to 8 mm diameter for search applications.

3 SPECIAL RETRIEVAL TOOLS

Custom made FOSAR solutions



Although we offer a big range of search and retrieval tools, sometimes the standard will not do the job. In the following chapter, we list some examples of our knowledge and expertise for successful custom made FOSAR solutions. Fortunately, some retrieval jobs are simple, fast and inexpensive. In certain cases, a complex task requires all our effort and resources.

In the end, all listed solutions solved problems saved our customers shutdown time and a lot of money. Fortunately, we can draw for your solution from a huge range of products, capabilities and experience. Feel free to contact us.



3.1 INVIZ® GR 22



INVIZ® GR 22 with integrated camera and LED illumination

| OUTER Ø | LENGTH | ARTICULATION | INNER Ø | FITTING PROBE Ø |
|---------|--------|--------------|---------|-----------------|
| 22.0 mm | 3 m | 4 x 110° | 9.0 mm | 9.0 mm |
| 22.0 mm | 5 m | 4 x 90° | 9.0 mm | 9.0 mm |

This sophisticated foreign object search and retrieval tool offers the same capabilities as the standard articulating guide tube INVIZ® GR 22. With its small integrated camera system and integrated LED illumination, search and retrieval jobs are performed fast and secure.

Utilizing the 15 mm retrieval pliers or the motorized retrieval tool INVIZ® GR 8, this system enables precise manoeuvring to find, monitor and retrieve the object immediately.

Retrieval snare 3.2

RETRIEVAL SNARE WITH EMERGENCY RELEASE MECHANISM

This remotely operated retrieval snare provides a special release mechanism and is positioned with an articulating guide tube. The chosen snare type ensures maximum pull strength.

If the part to retrieve would get stuck with the snare inside the application, the entire operation would be in danger. Therefore, a safety mechanism was integrated allowing the operator to remotely open up the snare. This solution results in pulling out only one string, thus allowing to reconnect attempt a new foreign object retrieval.

Retrieval snare with emergency release mechanism


INVIZ® GR 6



INVIZ® GR 6 with gas nozzle

ARTICULATING GUIDE TUBE INVIZ® GR 6 WITH WORKING CHANNEL AND GAS NOZZLE

This guide tube system with only 6 mm outer diameter contains a working channel allowing a micro tool or fiber bundle for a laser operation to pass. A special air/gas blow system can be connected and a true gas nozzle at the tip the tool can be cooled down, a specific protective gas environment can be created or simply air blown.



INVIZ® GR 10

JOYSTICK CONTROLLED, PNEUMATIC ARTICULATING GUIDE TUBE SYSTEM INVIZ® GR 10

Combined with the video endoscope system $INVIZ^{\otimes}$ VUMAN $^{\otimes}$ X-WAY, this remotely pneumatic articulating system is winded up and down from the patented drum reel. This system is mainly operated and utilized for foreign object retrieval, released vertically down from a scaffold or operation bridge. The INVIZ® GR 10 is capable of underwater operation and provides working lengths up to 30 m.

INVIZ® GR 25 3.5



INVIZ® GR 25

ARTICULATING GUIDE TUBE INVIZ® GR 25 WITH EXTRA-LARGE 12 MM WORKING CHANNEL

The INVIZ® GR 25 guide tubes key benefit is the articulation capability and the large 12 mm working channel. This feature allows passing through and remotely positioning strong flexible drive shafts for remote cutting, grinding opening, closing screws and other torque related tooling work. The large 12 mm working channel is also very well suited for sucking in bigger amounts of shavings and waste materials.

3.6 INVIZ® DE 2.4



INVIZ® DE 2.4 with retrieval hook

INVIZ® DE 2.4 WITH RETRIEVAL HOOK, WORKING CHANNEL FOR MICRO RETRIEVAL TOOLS

The INVIZ® DE 2.4 is a special probe, only 2.4 mm flat, integrating a retrieval hook in the distal head construction and a working channel inside the insertion belt. This solution has entered the secondary side of steam generators traveling in between the tube bundles. It helped to inspect and locate foreign objects, cut to big parts and retrieve foreign debris. This operation has restored safe operation conditions of steam generators, thus saving time and



viZaar industrial imaging AG

Hechinger Straße 152
72461 Albstadt / Germany
Tel: +49 7432 98375-0
Fax: +49 7432 98375-50
Freecall 0800 3600371 (only within Germany)
www.vizaar.de
info@vizaar.com

viZaar industrial imaging AG Vertriebs- und Dienstleistungszentrum Rhein-Main

Fürfurter Straße 105 65606 Villmar-Aumenau / Germany Tel.: +49 6474 8837-70

viZaar industrial imaging AG Vertriebs- und Dienstleistungszentrum Nord

Am Neuendeich 52 25348 Glückstadt / Germany Tel.: +49 4124 60819-40 Fax: +49 4124 60819-49

Fax: +49 6474 8837-90

viZaar industrial imaging AG Vertriebs- und Dienstleistungszentrum West

Burgstraße 27 46348 Raesfeld / Germany Tel.: +49 170 5703130



(viž





viZaar Industrial Imaging - North America

4533 Gibsonia Road
PA 15044 Gibsonia / USA
Tel.: +1 724 449-3270
Fax: +1 724 449-3273
www.vizaar-na.com
info@vizaar-na.com

viZaar Russia & CIS

197022, St. Petersburg, Professora Popova 37B Russia Tel.:+7 9852220677 www.vizaar.ru info@vizaar.ru

viZaar South-East Asia Sdn. Bhd.

2A Lrg Desa Utama Jln Masjid Kayu Ara PJU 6 47400 Petaling Jaya Selangor, Malaysia Tel.: +603 772 217-10

Fax: +603 772 217-10 www.vizaarsea.com.my info@vizaarsea.com.my

FORT SA

3 rue Lambert
Parc Lavoisier
91410 Dourdan / France
Tel.: +33 1608 11818
Fax: +33 1645 99573
www.fort-fr.com
info@fort-fr.com