

EasySmoker®

CamTronics

Fast and easy leak-testing with the EasySmoker

The EasySmoker enables you to quickly trace leaks in sewage, drainage ducts or even roof covers. With the EasySmoker you are off to a quick start in making a good analysis of the issue.

- Quickly reaches operating temperature
- Adjustable smoke quantity
- Adjustable airflow
- IP 44 waterproof
- Flexible 6 metre long hose for quick and easy coupling and insertion into a duct
- Easy refilling of smoke fluid into the internal 1,5 litre storage tank
- Compact design for efficient use of space



Quick start

After closing all of the normal exits of the duct you can, with the standard supplied hose and coupling head, fill the duct with smoke. The pressure build-up will then drive the smoke out through the leak. This enables you to trace the leak in a straightforward effective manner.

Abundant power

The powerful ventilator and the smoke-unit ensure a continuous sufficient supply of smoke. The EasySmoker is waterproof so that it can be used safely outdoors or in a wet working environment.

Options

The EasySmoker can be equipped with a number of smart accessories that will enhance its functionality and effectiveness. The EasySeal enables you to easily close and transfer smoke into a duct while the telescopic extension EasyStick with a length up to 4 metres, will help you to insert the hose into a deep cavity or high drainage duct. Special smoke fluid for the EasySmoker is available in a convenient 5 litre canister.



Tech
specs

EasySmoker®
CamTronics

EasySmoker

dimensions (excl. handle)	45x22x35 cm
weight	18 kg
storage tank (built-in)	1,5 litre
air pressure	adjustable
smoke intensity	adjustable
smoke element	electric
warm-up time	8 min
temperature	electron. controlled
quick connector (built-in)	50 mm
feet	rubber
power supply (mains)	230V
fan	1000 W
smoke element	1000 W
maximum power	2000 W
consumption	
maximum usage smoke liquid	1,8 litre/hr
maximum smoke capacity	5 m3/sec
maximum pressure	200 mbar
protection rating	IP44
temperature (usage)	-10 - 45 °C
temperature (storage)	-10 - 60 °C

Hose

length	6 m
diameter (internal)	50 mm
connector type	bayonet
connector diameter	50 mm

EasySeal

length	350 mm
weight	425 gr
diameter min	70 mm
diameter max	250 mm
diameter connector core	50 mm flexible

EasyStick

length min	170 cm
length max	400 cm
weight	1100 g
diameter clamp	50 mm

CamTronics
INNOVATIVE CAMERA SOLUTIONS

Camtronics BV | Ekkersrijt 3209 | 5692 CG
Son (Eindhoven) | NL | +31 (0)499 49 45 90

www.camtronics.eu